



The Odyssey **TOURING** is equipped with a number of convenience features that can be customized to your customer's preferences. Personalize the settings for your customer as listed below. Additional details are contained in the Owner's Manual, Quick Start Guide, and/or Features DVD (e.g., Navigation System, XM® Satellite Radio, and HomeLink®). NOTE: Default factory settings appear in **bold** print.

Note: Most features will be personalized using the vehicle	e's MID.
--	----------

VIN			
		RSONALIZATION	CUSTOMIZE MENU
1	Language Selection ENGLISH SPANISH FRENCH		COSTONIZE MENO OB:NEXT SELRESET:ENTER LANGUAGE SELECTION ►
2	Radio Presets Store up to 6 AM radio stations, 12 FM stations, an To store a station: (1) Use the tune, seek, or scan function to tune the radio to a desired station: (2) Pick a preset number button (1-6). (3) Push and hold it until you hear a beep. FM1		preset (1-6) buttons.
Ļ	XM1 XM2 X		CUSTOM SETUP
3	Vehicle lights go off after the driver removes the ignition key an 0 seconds 15 seconds 30 seconds	d closes the door.	HEADLIGHT AUTO OFF TIMER O sec
	Auto Door Lock Consult the Owner's Manual for instructions on how to set/chan Multi-Information Display.	ge the feature through the	AUTODOORLOCK VEHICLE SPEED
4	WITH VEHICLE SPEED Doors lock when vehicle speed SHIFT FROM "P" Doors lock when shift lever OFF Auto door lock function is defined	s moved out of Park (P).	
	Auto Door Unlock Consult the Owner's Manual for instructions on how to set/chan Multi-Information Display.	ge the feature through the	CUSTOMIZE MENU
5	DRIVER DOOR SHIFT TO "P" Driver's door unlocks when ALL DOORS SHIFT TO "P" All doors unlock when shift DRIVER DOOR IGNITION OFF Driver's door unlocks when ALL DOORS IGNITION OFF All doors unlock when igniti OFF/DEACTIVATED	lever is moved into Park (P). ignition is turned to LOCK (0). on is turned to LOCK (0).	
/	Remote Transmitter/Memory Seating Each remote transmitter activates the driver's seat position mer	norv system	
6	 (1) Instruct the customer to sit in the driver's seat and adjust the seat and door mirrors to preference. Set the memory for the seating according to driver preference (Driver 1 or 2). Advise the customer that the memory position is indicated on the remote transmitter. Confirm that the remote transmitter is linked to the vehicle. Consult the Driver's Memory Seating section of the vehicle's Owner's Manual for instructions. (2) Make sure to store the seat position in the memory of the transmitter that the customer will carry. 		
	Bluetooth® HandsFreeLink® (B-HFL) To view/confirm phone pairing information, go to handsfree or call the customer support line at (888) 528-7876. Then:		HFL TALK BUTTON
7	 Review Bluetooth phones that work best with Honda B-HFL and B-H Confirm that the customer's phone will function with HandsFreeLink. Turn ignition on and push OK on the navigation screen. Set up the phone to prepare for Bluetooth connection. If neither you nor the customer are able to successfully place and the customer still requires setup assistance, request the his/her phone owner's manual to the dealership for assistance Press the B-HFL TALK button and say "Phone setup, pair." Note: You will need to press the B-HFL TALK button each ti 	ce the phone into "Pairing Mode," at the customer bring a copy of nce.	NAVIGATION SYSTEM BUTTONS* *Refer to your navigation system manual.
	 (6) State "1-2-3-4" for the PIN. (7) Put the phone into search mode. (8) Select "HandsFreeLink" when it appears on the phone. (9) Enter PIN (1234) when prompted by the phone. <i>Accept Pairing a Phone if prompted.</i> (10) Have the customer name the phone (ideally using the customer's na (11) Ask the customer if it would be OK to call his/her cell phone to confin 	me).	
	NAVIGATION SYSTEM Set address for "go home" voice recognition command and GO	с, ,	vstem.
8	 Push the INFO button and use the joystick or touch screen to selectSET Use the joystick or touch screen to selectPERSONAL INFORMATION Use the joystick or touch screen to selectHOME ADDRESS. Select Edit NAME/ADDRESS and enter the customer's home address. Demonstrate the "Go Home" calculation. Show the customer the difference between the navigation and the HFL Show the customer the location of the microphone on the ceiling (speak Show the customer the Commonly Used Voice Commands in the Quich 	speech recognition buttons. and voice commands. imormal voice).	
*	(a) Show the customer the commonly used voice commands in the cuto Sales Consultant: Personalized settings instructions can be		very Training on the iN.
Customer's	s Name	Sales Consultant	Date
© 2007 Am	erican Honda Motor Co., Inc. – All Rights Reserved	Y0772	APS38023-38554 (0712)